


Monthly Wind Forecast Accuracy Report





NME is Normalised Mean Error, NMAE is Normalised Mean Absolute Error and NRMSE is Normalised Root Mean Squared Error

All statistics reported are normalised to the average total system installed wind capacity for the period analysed